



Grasshopper 718 Front Mount



REF. NO.	DESCRIPTION	REPLACES GRASSHOPPER NO.	STENS NO.
1.	Starter Solenoid	184251	435-099
2.	Carlisle Tire, 21-11.00-8, Power Trac II		165-104
3.	a. Blade for 52" deck, 2" W x 18" L x 1/2" CH	320236	320-044
	b. Hi-Lift Blade for 52" decks, 2" W x 18" L x 1/2" CH	320239	320-036
	c. Blade for 61" deck, 2 1/2" W x 21" L x 1/2" CH	320242	320-006
	d. Hi-Lift Blade for 61" deck, 2 1/2" W x 21" L x 1/2" CH	320245	320-014
4.	Right Hand Ball Joint	265615	245-019
5.	a. Deck Wheel Assembly, 9-3.50-4	603971	175-125
	b. Solid Tire Assembly, 9-3.50-4	603971	175-515
6.	Wheel Bearing	120050	215-370
7.	Pillow Block Bearing	122044/122043	230-437
8.	Spindle Bearing	110082/833210	230-102
9.	PTO Belt, cogged, 1/2" W x 36 3/8" L	381914	265-942
10.	Deck Mount Bushing	282575	225-837
11.	Transmission Filter	100850	120-471
12.	Starter Switch	183806	430-538
13.	PTO Switch	183925	430-330
14.	Seat Switch	183870	430-457
15.	Electric PTO Clutch (Warner 5218-27)	604180	255-319